



Plow Accessory and Service Kit Part List



UTV PUSH TUBE KIT 103760	ATV PUSH TUBE KIT 103780	ATV CENTER PUSH TUBE KIT 103790	50" PLOW BLADE KIT 103850	54" PLOW BLADE KIT 103754	60" PLOW BLADE KIT 103860	66" PLOW BLADE KIT 103866	72" PLOW BLADE KIT 103872
-----------------------------------	-----------------------------------	---	------------------------------------	------------------------------------	------------------------------------	------------------------------------	------------------------------------

	KIT #	DESCRIPTION	KIT PART NUMBER							
	Accessory & Upgrade Kits	1	Wear Bar UHMW	N/A	N/A	N/A	109150	109148	109146	109144
2		Plow Lift Pulley	109288	109288	109288	N/A	N/A	N/A	N/A	N/A
3		Power-Pivot Plow - ATV	103810	103810	103810	N/A	N/A	N/A	N/A	N/A
4		Power-Pivot Plow - UTV	103840	103840	103840	N/A	N/A	N/A	N/A	N/A
5		ATV/UTV Plow Extension	109310	109310	109310	N/A	N/A	N/A	N/A	N/A
6		Universal Rubber Snow Flap	N/A	N/A	N/A	109156	109156	109156	109156	109156
7		Snow Control Plow Blade	N/A	N/A	N/A	103820	103820	103820	103820	103820
Service Kits	8	Plow Skids	N/A	N/A	N/A	109354	109354	109354	109354	109354
	9	Hardware Push Tubes	109324	109324	109324	N/A	N/A	N/A	N/A	N/A
	10	Push Tubes	109325	109333	109329	N/A	N/A	N/A	N/A	N/A
	11	Swivel Base	109334	109334	109334	N/A	N/A	N/A	N/A	N/A
	12	Push Tube Swivel Bushing	109335	109335	109335	N/A	N/A	N/A	N/A	N/A
	13	Push Tube Retainer	109336	109336	109336	N/A	N/A	N/A	N/A	N/A
	14	Plow Springs	N/A	N/A	N/A	109469	109469	109469	109469	109469
	15	Hook Eye	109340	109340	109340	N/A	N/A	N/A	N/A	N/A
	16	Steel Wear Bar	N/A	N/A	N/A	109341	109342	109343	109344	109345
	17	Steel Wear Bar Hardware	N/A	N/A	N/A	109323	109323	109323	109323	109323
	18	Power Pivot Wiring	108924	108924	108924	N/A	N/A	N/A	N/A	N/A
	19	Power Pivot Brackets	108925	108925	108925	N/A	N/A	N/A	N/A	N/A
	20	Power Pivot Ram	108926	108926	108926	N/A	N/A	N/A	N/A	N/A

Push Tube Service Kit Part List

SERVICE KIT	DESCRIPTION	MAJOR PARTS
9	Hardware Push Tubes	A
10	Push Tubes*	B*
11	Swivel Base	C
12	Push Tube Swivel Bushing	D
13	Push Tube Retainer	E
15	Hook Eye	F


* WARN® offers multiple push tube configurations. Your specific product may look slightly different than illustration.






Plow Blade Accessory and Service Kit Part List

ACCESSORY KIT	DESCRIPTION	MAJOR PARTS
1	Wear Bar UHMW	G

G








SERVICE KIT	DESCRIPTION	MAJOR PARTS
8	Plow Skids	H
14	Plow Springs	I
16	Steel Wear Bar	J
17	Steel Wear Bar Hardware	K



Plow Accessory and Service Kit Part List

ACCESSORY KIT	DESCRIPTION	MAJOR PARTS
2	Plow Lift Pulley	L
3	Power-Pivot Plow - ATV	M
4	Power-Pivot Plow - UTV	N
5	ATV/UTV Plow Extension	O
6	Universal Rubber Snow Flap	P
7	Snow Control Plow Blade	Q



SERVICE KIT	DESCRIPTION	MAJOR PARTS
18	Power Pivot Wiring	R
19	Power Pivot Brackets	S
20	Power Pivot Ram	T

